

| Model Number comparing list | | |
|-----------------------------|-------------------|------------|
| Product Number | Size IDxODxL (mm) | SKF |
| FB090 1010 | 10x12x10 | PRM 1010 |
| FB090 1015 | 10x12x15 | PRM 1015 |
| FB090 1020 | 10x12x20 | PRM 1020 |
| FB090 1210 | 12x14x10 | PRM 1210 |
| FB090 1215 | 12x14x15 | PRM 1215 |
| FB090 1220 | 12x14x20 | PRM 1220 |
| FB090 1410 | 14x16x10 | PRM 1410 |
| FB090 1415 | 14x16x15 | PRM 1415 |
| FB090 1420 | 14x16x20 | PRM 1420 |
| FB090 1425 | 14x16x25 | PRM 1425 |
| FB090 1510 | 15x17x10 | PRM 1510 |
| FB090 1515 | 15x17x15 | PRM 1515 |
| FB090 1520 | 15x17x20 | PRM 1520 |
| FB090 1525 | 15x17x25 | PRM 1525 |
| FB090 1610 | 16x18x10 | PRM 1610 |
| FB090 1615 | 16x18x15 | PRM 1615 |
| FB090 1620 | 16x18x20 | PRM 1620 |
| FB090 1625 | 16x18x25 | PRM 1625 |
| FB090 1810 | 18x20x10 | PRM 1810 |
| FB090 1815 | 18x20x15 | PRM 1815 |
| FB090 1820 | 18x20x20 | PRM 1820 |
| FB090 1825 | 18x20x25 | PRM 1825 |
| FB090 182115 | 18x21x15 | PRM 182115 |
| FB090 182120 | 18x21x20 | PRM 182120 |
| FB090 182125 | 18x21x25 | PRM 182125 |
| FB090 202210 | 20x22x10 | PRM 202210 |
| FB090 202215 | 20x22x15 | PRM 202215 |
| FB090 202220 | 20x22x20 | PRM 202220 |
| FB090 202225 | 20x22x25 | PRM 202225 |
| FB090 2010 | 20x23x10 | PRM 2010 |
| FB090 2015 | 20x23x15 | PRM 2015 |
| FB090 2020 | 20x23x20 | PRM 2020 |
| FB090 2025 | 20x23x25 | PRM 2025 |
| FB090 2030 | 20x23x30 | PRM 2030 |
| FB090 2210 | 22x25x10 | PRM 2210 |
| FB090 2215 | 22x25x15 | PRM 2215 |
| FB090 2220 | 22x25x20 | PRM 2220 |
| FB090 2225 | 22x25x25 | PRM 2225 |
| FB090 2230 | 22x25x30 | PRM 2230 |
| FB090 2410 | 24x27x10 | PRM 242710 |
| FB090 2415 | 24x27x15 | PRM 242715 |
| FB090 2420 | 24x27x20 | PRM 242720 |
| FB090 2425 | 24x27x25 | PRM 242725 |
| FB090 242810 | 24x28x10 | PRM 2410 |
| FB090 242815 | 24x28x15 | PRM 2415 |
| FB090 242820 | 24x28x20 | PRM 2420 |

| | | |
|--------------|----------|------------|
| FB090 242825 | 24x28x25 | PRM 2425 |
| FB090 242830 | 24x28x30 | PRM 2430 |
| FB090 2515 | 25x28x15 | PRM 2515 |
| FB090 2520 | 25x28x20 | PRM 2520 |
| FB090 2525 | 25x28x25 | PRM 2525 |
| FB090 2530 | 25x28x30 | PRM 2530 |
| FB090 2550 | 25x28x50 | PRM 2550 |
| FB090 283115 | 28x31x15 | PRM 283115 |
| FB090 283120 | 28x31x20 | PRM 283120 |
| FB090 283125 | 28x31x25 | PRM 283125 |
| FB090 283130 | 28x31x30 | PRM 283130 |
| FB090 2815 | 28x32x15 | PRM 2815 |
| FB090 2820 | 28x32x20 | PRM 2820 |
| FB090 2825 | 28x32x25 | PRM 2825 |
| FB090 2830 | 28x32x30 | PRM 2830 |
| FB090 3015 | 30x34x15 | PRM 3015 |
| FB090 3020 | 30x34x20 | PRM 3020 |
| FB090 3025 | 30x34x25 | PRM 3025 |
| FB090 3030 | 30x34x30 | PRM 3030 |
| FB090 3035 | 30x34x35 | PRM 3035 |
| FB090 3040 | 30x34x40 | PRM 3040 |
| FB090 3215 | 32x36x15 | PRM 3215 |
| FB090 3220 | 32x36x20 | PRM 3220 |
| FB090 3225 | 32x36x25 | PRM 3225 |
| FB090 3230 | 32x36x30 | PRM 3230 |
| FB090 3235 | 32x36x35 | PRM 3235 |
| FB090 3240 | 32x36x40 | PRM 3240 |
| FB090 3520 | 35x39x20 | PRM 3520 |
| FB090 3525 | 35x39x25 | PRM 3525 |
| FB090 3530 | 35x39x30 | PRM 3530 |
| FB090 3540 | 35x39x40 | PRM 3540 |
| FB090 3550 | 35x39x50 | PRM 3550 |
| FB090 4020 | 40x44x20 | PRM 4020 |
| FB090 4025 | 40x44x25 | PRM 4025 |
| FB090 4030 | 40x44x30 | PRM 4030 |
| FB090 4035 | 40x44x35 | PRM 4035 |
| FB090 4040 | 40x44x40 | PRM 4040 |
| FB090 4050 | 40x44x50 | PRM 4050 |
| FB090 4520 | 45x50x20 | PRM 4520 |
| FB090 4525 | 45x50x25 | PRM 4525 |
| FB090 4530 | 45x50x30 | PRM 4530 |
| FB090 4535 | 45x50x35 | PRM 4535 |
| FB090 4540 | 45x50x40 | PRM 4540 |
| FB090 4550 | 45x50x50 | PRM 4550 |
| FB090 4560 | 45x50x50 | PRM 4560 |
| FB090 5020 | 50x55x20 | PRM 5020 |
| FB090 5025 | 50x55x25 | PRM 5025 |
| FB090 5030 | 50x55x30 | PRM 5030 |

| | | |
|------------|----------|----------|
| FB090 5035 | 50x55x35 | PRM 5035 |
| FB090 5040 | 50x55x40 | PRM 5040 |
| FB090 5050 | 50x55x50 | PRM 5050 |
| FB090 5060 | 50x55x60 | PRM 5060 |
| FB090 5520 | 55x60x20 | PRM 5520 |
| FB090 5525 | 55x60x25 | PRM 5525 |
| FB090 5530 | 55x60x30 | PRM 5530 |
| FB090 5535 | 55x60x35 | PRM 5535 |
| FB090 5540 | 55x60x40 | PRM 5540 |
| FB090 5550 | 55x60x50 | PRM 5550 |
| FB090 5560 | 55x60x60 | PRM 5560 |
| FB090 6025 | 60x65x25 | PRM 6025 |
| FB090 6030 | 60x65x30 | PRM 6030 |
| FB090 6035 | 60x65x35 | PRM 6035 |
| FB090 6040 | 60x65x40 | PRM 6040 |
| FB090 6045 | 60x65x45 | PRM 6045 |
| FB090 6050 | 60x65x50 | PRM 6050 |
| FB090 6060 | 60x65x60 | PRM 6060 |
| FB090 6070 | 60x65x70 | PRM 6070 |
| FB090 6530 | 65x70x30 | PRM 6530 |
| FB090 6535 | 65x70x35 | PRM 6535 |
| FB090 6540 | 65x70x40 | PRM 6540 |
| FB090 6550 | 65x70x50 | PRM 6550 |
| FB090 6560 | 65x70x60 | PRM 6560 |
| FB090 6570 | 65x70x70 | PRM 6570 |
| FB090 7030 | 70x75x30 | PRM 7030 |
| FB090 7035 | 70x75x35 | PRM 7035 |
| FB090 7040 | 70x75x40 | PRM 7040 |
| FB090 7045 | 70x75x45 | PRM 7045 |
| FB090 7050 | 70x75x50 | PRM 7050 |
| FB090 7060 | 70x75x60 | PRM 7060 |
| FB090 7070 | 70x75x80 | PRM 7070 |
| FB090 7530 | 75x80x30 | PRM 7530 |
| FB090 7535 | 75x80x35 | PRM 7535 |
| FB090 7540 | 75x80x40 | PRM 7540 |
| FB090 7550 | 75x80x50 | PRM 7550 |
| FB090 7560 | 75x80x60 | PRM 7560 |
| FB090 7570 | 75x80x70 | PRM 7570 |
| FB090 7580 | 75x80x80 | PRM 7580 |
| FB090 8030 | 80x85x30 | PRM 8030 |
| FB090 8035 | 80x85x35 | PRM 8035 |
| FB090 8040 | 80x85x40 | PRM 8040 |
| FB090 8050 | 80x85x50 | PRM 8050 |
| FB090 8060 | 80x85x60 | PRM 8060 |
| FB090 8070 | 80x85x70 | PRM 8070 |
| FB090 8080 | 80x85x80 | PRM 8080 |
| FB090 8530 | 85x90x30 | PRM 8530 |
| FB090 8535 | 85x90x35 | PRM 8535 |

| | | |
|--------------|-------------|------------|
| FB090 8540 | 85x90x40 | PRM 8540 |
| FB090 8550 | 85x90x50 | PRM 8550 |
| FB090 8560 | 85x90x60 | PRM 8560 |
| FB090 8570 | 85x90x70 | PRM 8570 |
| FB090 8580 | 85x90x80 | PRM 8580 |
| FB090 8590 | 85x90x90 | PRM 8590 |
| FB090 9030 | 90x95x30 | PRM 9030 |
| FB090 9035 | 90x95x35 | PRM 9035 |
| FB090 9040 | 90x95x40 | PRM 9040 |
| FB090 9050 | 90x95x50 | PRM 9050 |
| FB090 9060 | 90x95x60 | PRM 9060 |
| FB090 9070 | 90x95x70 | PRM 9070 |
| FB090 9080 | 90x95x80 | PRM 9080 |
| FB090 9090 | 90x95x90 | PRM 9090 |
| FB090 90100 | 90x95x100 | PRM 90200 |
| FB090 9540 | 95x100x40 | PRM 9540 |
| FB090 9550 | 95x100x50 | PRM 9550 |
| FB090 9560 | 95x100x60 | PRM 9560 |
| FB090 9570 | 95x100x70 | PRM 9570 |
| FB090 9580 | 95x100x80 | PRM 9580 |
| FB090 9590 | 95x100x90 | PRM 9590 |
| FB090 95100 | 95x100x100 | PRM 95100 |
| FB090 10040 | 100x105x40 | PRM 10040 |
| FB090 10050 | 100x105x50 | PRM 10050 |
| FB090 10060 | 100x105x60 | PRM 10060 |
| FB090 10070 | 100x105x70 | PRM 10070 |
| FB090 10080 | 100x105x80 | PRM 10080 |
| FB090 10090 | 100x105x90 | PRM 10090 |
| FB090 10095 | 100x105x95 | PRM 10095 |
| FB090 100100 | 100x105x100 | PRM 100100 |
| FB090 10550 | 105x110x50 | PRM 10550 |
| FB090 10560 | 105x110x60 | PRM 10560 |
| FB090 10570 | 105x110x70 | PRM 10570 |
| FB090 10580 | 105x110x80 | PRM 10580 |
| FB090 10590 | 105x110x90 | PRM 10590 |
| FB090 105100 | 105x110x100 | PRM 105100 |
| FB090 11050 | 110x115x50 | PRM 11050 |
| FB090 11060 | 110x115x60 | PRM 11060 |
| FB090 11070 | 110x115x70 | PRM 11070 |
| FB090 11080 | 110x115x80 | PRM 11080 |
| FB090 11090 | 110x115x90 | PRM 11090 |
| FB090 11095 | 110x115x95 | PRM 11095 |
| FB090 110100 | 110x115x100 | PRM 110100 |
| FB090 11550 | 115x120x50 | PRM 11550 |
| FB090 11560 | 115x120x60 | PRM 11560 |
| FB090 11570 | 115x120x70 | PRM 11570 |
| FB090 11580 | 115x120x80 | PRM 11580 |
| FB090 11590 | 115x120x90 | PRM 11590 |

| | | |
|--------------|-------------|------------|
| FB090 115100 | 115x120x100 | PRM 115100 |
| FB090 12025 | 120x125x25 | PRM 12025 |
| FB090 12050 | 120x125x50 | PRM 12050 |
| FB090 12060 | 120x125x60 | PRM 12060 |
| FB090 12070 | 120x125x70 | PRM 12070 |
| FB090 12080 | 120x125x80 | PRM 12080 |
| FB090 12090 | 120x125x90 | PRM 12090 |
| FB090 12095 | 120x125x95 | PRM 12095 |
| FB090 120100 | 120x125x100 | PRM 120100 |
| FB090 12560 | 125x130x60 | PRM 12560 |
| FB090 12570 | 125x130x70 | PRM 12570 |
| FB090 12580 | 125x130x80 | PRM 12580 |
| FB090 12590 | 125x130x90 | PRM 12590 |
| FB090 125100 | 125x130x100 | PRM 125100 |
| FB090 13060 | 130x135x60 | PRM 13060 |
| FB090 13070 | 130x135x70 | PRM 13070 |
| FB090 13080 | 130x135x80 | PRM 13080 |
| FB090 13090 | 130x135x90 | PRM 13090 |
| FB090 130100 | 130x135x100 | PRM 130100 |
| FB090 13560 | 135x140x60 | PRM 13560 |
| FB090 13570 | 135x140x70 | PRM 13570 |
| FB090 13580 | 135x140x80 | PRM 13580 |
| FB090 13590 | 135x140x90 | PRM 13590 |
| FB090 135100 | 135x140x100 | PRM 135100 |
| FB090 14050 | 140x145x50 | PRM 14050 |
| FB090 14060 | 140x145x60 | PRM 14060 |
| FB090 14070 | 140x145x70 | PRM 14070 |
| FB090 14080 | 140x145x80 | PRM 14080 |
| FB090 14090 | 140x145x90 | PRM 14090 |
| FB090 140100 | 140x145x100 | PRM 140100 |
| FB090 14560 | 145x150x60 | PRM 14560 |
| FB090 14570 | 145x150x70 | PRM 14570 |
| FB090 14580 | 145x150x80 | PRM 14580 |
| FB090 14590 | 145x150x90 | PRM 14590 |
| FB090 145100 | 145x150x100 | PRM 145100 |
| FB090 15045 | 150x155x45 | PRM 15060 |
| FB090 15060 | 150x155x60 | PRM 15060 |
| FB090 15070 | 150x155x70 | PRM 15070 |
| FB090 15080 | 150x155x80 | PRM 15080 |
| FB090 15090 | 150x155x90 | PRM 15090 |
| FB090 150100 | 150x155x100 | PRM 150100 |
| FB090 15560 | 155x160x60 | PRM 15560 |
| FB090 15570 | 155x160x70 | PRM 15570 |
| FB090 15580 | 155x160x80 | PRM 15580 |
| FB090 15590 | 155x160x90 | PRM 15590 |
| FB090 155100 | 155x160x100 | PRM 155100 |
| FB090 16060 | 160x165x60 | PRM 16060 |
| FB090 16070 | 160x165x70 | PRM 16070 |

| | | |
|--------------|-------------|------------|
| FB090 16080 | 160x165x80 | PRM 16080 |
| FB090 16090 | 160x165x90 | PRM 16090 |
| FB090 160100 | 160x165x100 | PRM 160100 |
| FB090 16560 | 165x170x60 | PRM 16560 |
| FB090 16570 | 165x170x70 | PRM 16570 |
| FB090 16580 | 165x170x80 | PRM 16580 |
| FB090 16590 | 165x170x90 | PRM 16590 |
| FB090 165100 | 165x170x100 | PRM 165100 |
| FB090 17060 | 170x175x60 | PRM 17060 |
| FB090 17070 | 170x175x70 | PRM 17070 |
| FB090 17080 | 170x175x80 | PRM 17080 |
| FB090 17090 | 170x175x90 | PRM 17090 |
| FB090 170100 | 170x175x100 | PRM 170100 |
| FB090 17550 | 175x180x50 | PRM 17550 |
| FB090 17560 | 175x180x60 | PRM 17560 |
| FB090 17570 | 175x180x70 | PRM 17570 |
| FB090 17580 | 175x180x80 | PRM 17580 |
| FB090 17590 | 175x180x90 | PRM 17590 |
| FB090 175100 | 175x180x100 | PRM 175100 |
| FB090 18045 | 180x185x45 | PRM 18045 |
| FB090 18060 | 180x185x60 | PRM 18060 |
| FB090 18070 | 180x185x70 | PRM 18070 |
| FB090 18080 | 180x185x80 | PRM 18080 |
| FB090 18090 | 180x185x90 | PRM 18090 |
| FB090 180100 | 180x185x100 | PRM 180100 |
| FB090 18560 | 185x190x60 | PRM 18560 |
| FB090 18570 | 185x190x70 | PRM 18570 |
| FB090 18580 | 185x190x80 | PRM 18580 |
| FB090 18590 | 185x190x90 | PRM 18590 |
| FB090 185100 | 185x190x100 | PRM 185100 |
| FB090 19060 | 190x195x60 | PRM 19060 |
| FB090 19070 | 190x195x70 | PRM 19070 |
| FB090 19080 | 190x195x80 | PRM 19080 |
| FB090 19090 | 190x195x90 | PRM 19090 |
| FB090 190100 | 190x195x100 | PRM 190100 |
| FB090 19560 | 195x200x60 | PRM 19560 |
| FB090 19570 | 195x200x70 | PRM 19570 |
| FB090 19580 | 195x200x80 | PRM 19580 |
| FB090 19590 | 195x200x90 | PRM 19590 |
| FB090 195100 | 195x200x100 | PRM 195100 |
| FB090 20060 | 200x205x60 | PRM 20060 |
| FB090 20070 | 200x205x70 | PRM 20070 |
| FB090 20080 | 200x205x80 | PRM 20080 |
| FB090 20090 | 200x205x90 | PRM 20090 |
| FB090 200100 | 200x205x100 | PRM 200100 |
| FB090 20560 | 205x210x60 | PRM 20560 |
| FB090 20570 | 205x210x70 | PRM 20570 |
| FB090 20580 | 205x210x80 | PRM 20580 |

| | | |
|--------------|-------------|------------|
| FB090 20590 | 205x210x90 | PRM 20590 |
| FB090 205100 | 205x210x100 | PRM 205100 |
| FB090 21060 | 210x215x60 | PRM 21060 |
| FB090 21070 | 210x215x70 | PRM 21070 |
| FB090 21080 | 210x215x80 | PRM 21080 |
| FB090 21090 | 210x215x90 | PRM 21090 |
| FB090 210100 | 210x215x100 | PRM 210100 |
| FB090 21560 | 215x220x60 | PRM 21560 |
| FB090 21570 | 215x220x70 | PRM 21570 |
| FB090 21580 | 215x220x80 | PRM 21580 |
| FB090 21590 | 215x220x90 | PRM 21590 |
| FB090 215100 | 215x220x100 | PRM 215100 |
| FB090 22060 | 220x225x60 | PRM 22060 |
| FB090 22070 | 220x225x70 | PRM 22070 |
| FB090 22080 | 220x225x80 | PRM 22080 |
| FB090 22090 | 220x225x90 | PRM 22090 |
| FB090 220100 | 220x225x100 | PRM 220100 |
| FB090 22560 | 225x230x60 | PRM 22560 |
| FB090 22570 | 225x230x70 | PRM 22570 |
| FB090 22580 | 225x230x80 | PRM 22580 |
| FB090 22590 | 225x230x90 | PRM 22590 |
| FB090 225100 | 225x230x100 | PRM 225100 |
| FB090 23060 | 230x235x60 | PRM 23060 |
| FB090 23070 | 230x235x70 | PRM 23070 |
| FB090 23080 | 230x235x80 | PRM 23080 |
| FB090 23090 | 230x235x90 | PRM 23090 |
| FB090 230100 | 230x235x100 | PRM 230100 |
| FB090 24060 | 240x245x60 | PRM 24060 |
| FB090 24070 | 240x245x70 | PRM 24070 |
| FB090 24080 | 240x245x80 | PRM 24080 |
| FB090 24090 | 240x245x90 | PRM 24090 |
| FB090 240100 | 240x245x100 | PRM 240100 |
| FB090 25060 | 250x255x60 | PRM 25060 |
| FB090 25070 | 250x255x70 | PRM 25070 |
| FB090 25080 | 250x255x80 | PRM 25080 |
| FB090 25090 | 250x255x90 | PRM 25090 |
| FB090 250100 | 250x255x100 | PRM 250100 |
| FB090 26060 | 260x265x60 | PRM 26060 |
| FB090 26070 | 260x265x70 | PRM 26070 |
| FB090 26080 | 260x265x80 | PRM 26080 |
| FB090 26090 | 260x265x90 | PRM 26090 |
| FB090 260100 | 260x265x100 | PRM 260100 |
| FB090 27060 | 270x275x60 | PRM 27060 |
| FB090 27070 | 270x275x70 | PRM 27070 |
| FB090 27080 | 270x275x80 | PRM 27080 |
| FB090 27090 | 270x275x90 | PRM 27090 |
| FB090 270100 | 270x275x100 | PRM 270100 |
| FB090 28060 | 280x285x60 | PRM 28060 |

| | | |
|--------------|-------------|------------|
| FB090 28070 | 280x285x70 | PRM 28070 |
| FB090 28080 | 280x285x80 | PRM 28080 |
| FB090 28090 | 280x285x90 | PRM 28090 |
| FB090 280100 | 280x285x100 | PRM 280100 |
| FB090 29060 | 290x295x60 | PRM 29060 |
| FB090 29070 | 290x295x70 | PRM 29070 |
| FB090 29080 | 290x295x80 | PRM 29080 |
| FB090 29090 | 290x295x90 | PRM 29090 |
| FB090 290100 | 290x295x100 | PRM 290100 |
| FB090 30060 | 300x305x60 | PRM 30060 |
| FB090 30070 | 300x305x70 | PRM 30070 |
| FB090 30080 | 300x305x80 | PRM 30080 |
| FB090 30090 | 300x305x90 | PRM 30090 |
| FB090 300100 | 300x305x100 | PRM 300100 |